

Maintenance of Headset

Agenda

- Maintenance of the corded Headset;
- Maintenance of the wireless Headset;
- Maintenance of the Bluetooth Headset;

Maintenance of Corded Headset




Maintenance of Corded Headset

Don't:

Don't

- Force to rotate the “Click Stop Turret” within adjustable range;




Don't

- Twine the cable round the headband, or twist frequently the cable;




Don't

- Use sharp object to unclog the voice tube;



Don't


- Use headset when have dinner and drink water;



Avoid the food and water to stick the headset, which will cut down the useful time of headset

Don't


- Use solvents or wet cloth to clean cable;



Plastic parts is easy to be become fragile and crazed by solvents. If the wiping cloth has too much water, it will make the headset to short-circuit.

Don't

- Put the cable on the board;



Avoid the chair to run over QD connector or person to step on the QD connector, which will damage QD connector

Don't

- Pull hard QD cable;



Easy to be short-circuited and cut down the useful time of headset


Do

Do

- Handle gently;
- Replace voice tube every 6-9 months (voice tube models only);
- Clean the voice tube once a month;
- Replace ear cushion every six months;
- Clean cable with a damp cloth once a month;

Do

- Avoid to make the headset overheating or super cooling;



High temperature will make the plastic part deformed, and low temperature will make the headset fragile


Do

- Use the cloth bag to stow the headset;

Avoid to be pressed by other goods when the headset is stowed in the drawer, which will avoid the headset's cable or headband to be broken

Do

- Beware of the static;



Too much static will damage the headset

Do

- If use amplifier, replace regularly the batteries;

Do

– To clean the Voice Tube:

- » Remove the Voice Tube from the Headset and place it in the warm water ;
- » Stir or agitate vigorously for one minute after four minute intervals of soaking for twenty minutes total;
- » Tap or flick-out excess water and allow to dry;
- » Reattach Voice Tube on Headset and asses extent of improvement by talking into it;

Maintenance of Wireless Headset





Don't

Don't


- Use headset when have dinner and drink water;
- Use solvents, other cleaning agents or wet cloth to clean the equipment;

Do

Do

- Handle gently;
- Please charge the headset for minimum 30 minutes before using it for the first time;
- Unplug the unit from the telephone and the AC charger from the power source before cleaning;
- Clean the equipment with a damp (not wet) cloth;
- Avoid to make the headset overheating or super cooling;

Maintenance of Bluetooth Headset





Don't

Don't

- Use headset when have dinner and drink water;
- Use solvents or other cleaning agents to clean the equipment;
- Plug/pull hard AC power adaptor when charging;

Damage the charge connector of headset



Do

Do

- Handle gently;
- Please charge the headset for minimum 30 minutes before using it for the first time;
- Do not charge the headset while headset is on;
- Avoid to make the headset overheating or super cooling;
- Do not use when the headset is charged;



Influence the audio function of headset



The End